

Metrologic Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode




999999

2. Load Keyboard Wedge Defaults




999994

3. Configuration Code 1



8162370

4. Exit Program Mode



999999